

**prompt<sup>®</sup>**




**MILKEASY**

milking machine



**Designed for Efficiency  
and Performance**

# prompt<sup>®</sup> MILKEASY



## **Pulsator**

60 Pulse per minute  
60:40 Pulse ratio

## **Vacuum Tank**

Powder coated  
Easy to clean

## **Milk Bucket**

25 Lit. capacity  
S.S 304 body  
Easy to clean

## **Vacuum Pump**

Mono-block type  
Stable vacuum  
Low noise  
Single phase motor

## **Trolley**

Strong structure  
Powder coated  
Robust wheel

## **Cluster Set**

Weight- 2.5 kg  
Strong and durable quality

## **High-Quality Rubber Liners**

Designed for effective  
udder massage

## **Milk Tube**

Enough length  
Transparent  
Easy to clean  
Food grade material

## FEATURES:

- Easy-to-move trolley with large heavy duty wheels
- Strongly built for tough conditions
- Single to six buckets machines available
- 25 litre stainless steel 304 buckets
- Electric motor – Direct coupling with vacuum pump, having highest level of safety
- Low noise to avoid any discomfort to the cattle
- Long working life of machine
- Milk tube is transparent, easy to clean and has food-grade, non-toxic quality standards
- Premium quality of clusters and liners used to ensure cattle comfort
- Interlocking to prevent injury to cattle

## WHAT ARE ITS BENEFITS?

- Limits bacterial growth
- Better udder health
- Maximizes milk yield
- Retains milk quality
- Easy to set-up & start
- Designed to ensure animal comfort and cleaning
- Reduces dependency on skilled farm workers
- Much faster than milking by hand
- Highly efficient and easy to operate
- More time available for the farmer to manage the farm



## Type of Milking Machines:

### Milking Machine PRM - 1



Mobile Milking Machine	
Model	PRM-1 (Single Bucket Single Cluster)
Cattle per hour	8-10
Milking cup group number	1 Set
Working vacuum	40-50 kpa (adjustable)
Pulsation ratio	60:40
Pulsation time	60-80tpm
Vacuum pump power	0.5 hp
Pump Capacity	200 LPM

### Milking Machine PRM - 2



Mobile Milking Machine	
Model	PRM-2 (Double Bucket Double Cluster)
Cattle per hour	20-24
Milking cup group number	2 Set
Working vacuum	40-50 kpa (adjustable)
Pulsation ratio	60:40
Pulsation time	60-80tpm
Vacuum pump power	1 hp
Pump Capacity	240 LPM

### Milking Machine PRM - 1D



Mobile Milking Machine	
Model	PRM-1D (Single Bucket Double Cluster)
Cattle per hour	16-20
Milking cup group number	2 Set
Working vacuum	40-50 kpa (adjustable)
Pulsation ratio	60:40
Pulsation time	60-80tpm
Vacuum pump power	1 hp
Pump Capacity	240 LPM

### Milking Machine PRM - 1F




Mobile Milking Machine	
Model	PRM-1F (Single Bucket Single Cluster)
Cattle per hour	8-10
Milking cup group number	1 Set
Working vacuum	40-50 kpa (adjustable)
Pulsation ratio	60:40
Pulsation time	60-80tpm
Vacuum pump power	1 hp
Pump Capacity	240 LPM

### Milking Machine PRM - 2F



Mobile Milking Machine	
Model	PRM-2F (Double Bucket Double Cluster)
Cattle per hour	20-24
Milking cup group number	2 Set
Working vacuum	40-50 kpa (adjustable)
Pulsation ratio	60:40
Pulsation time	60-80tpm
Vacuum pump power	1 hp
Pump Capacity	240 LPM

### Milking Machine PRM - 4F



Mobile Milking Machine	
Model	PRM-4F (Double Bucket Double Cluster)
Cattle per hour	40-48
Milking cup group number	4 Set
Working vacuum	40-50 kpa (adjustable)
Pulsation ratio	60:40
Pulsation time	60-80tpm
Vacuum pump power	1.5 hp
Pump Capacity	400 LPM



Our ideas and innovations are a part of the pursuit of maintaining the sanctity of milk so that the world's most ancient health drink can be appreciated as it truly is – untouched and unadulterated.



28+ states



350+ districts



68,000+ villages



900+ team members



Legacy of over 3 decades



10 patented products



220+ serviceable locations



24x7 support via mobile app

## Optimise your farm with other related products

### BovEasy - Bovine Pregnancy Rapid Test Kit

The BovEasy Bovine Pregnancy Rapid Test Kit is a game changer in bovine reproductive management. Combining precision, affordability, and speed, it offers accurate pregnancy detection in just 20 minutes. This easy to use kit empowers farmers and veterinarians with reliable results, optimizing breeding strategies and herd health while minimizing waiting time and costs.



### Farm 365 - Dairy Farm Management App

This technologically advanced app is a complete solution to your cattle management needs, which helps improve cattle breeding and feeding resulting in increased milk yield and profitability.



### Prompt Equipments Pvt. Ltd.

7th Floor, Shaligram Corporates, C. J. Road, Iskon - Ambli Road, Ahmedabad Gujarat - 380058 (India)  
[info@promptdairytech.com](mailto:info@promptdairytech.com) | [www.promptdairytech.com](http://www.promptdairytech.com)

Ph: 02717 45 1111/6111 | Follow us on   